




**EVAC CONTROL ON THE ADDITIONAL ATTENDANT PANEL (AAP)**

Note:    *Additional Attendant Panels (AAPs) with EVAC control are optional.*

Typical EVAC Control on an Additional Attendant Panel (AAP)



	Button	Description
	EVAC	Depending on the configuration of the Cabin Assignment Module (CAM), the cabin crew can use the EVAC button for either one of the following actions: <ul style="list-style-type: none"><li>- Start the evacuation aural alert in the cabin as well as the EVAC indication on the Attendant Indication Panels (AIPs), or</li><li>- Activate an evacuation request.</li></ul> For both operations there is confirmation pop up requesting the cabin crew to confirm or cancel the action.
	EVAC RESET	The cabin crew can use the EVAC RESET button to turn OFF the evacuation aural alert in the cabin as well as the EVAC indication on the AIPs.

**DESCRIPTION OF THE AURAL AND VISUAL ALERTS IN THE CABIN**

Applicable to: ALL OSD

An active evacuation command alerts the cabin crew and the passengers with aural and visual signals in the cabin.

**AURAL EVAC SIGNAL**

The EVAC signal sounds throughout the whole cabin via the cabin loudspeakers.

**VISUAL EVAC SIGNAL**

The visual EVAC signals are indicated on the:

- Flight Attendant Panels (FAPs)
- Additional Indication Panels (AIPs).

**FAP**

On all FAPs the EVAC RESET hardkey flashes red.

**AAP**

Optionally there is an EVAC RESET button on AAPs that flashes amber.