

 <p>A350 MANUEL SECURITE SAUVETAGE</p>	<p>CABIN LAYOUT</p> <p>CABIN CREW REST AREAS</p> <p>DESCRIPTION/OPERATION</p>
---	---

HOW TO OPERATE THE DOOR IF REGULAR OPERATION IS NOT POSSIBLE

How to Open the Door from Inside the CCRC

1. Shift the handle of the manual door opener to unlock the door.

How to Operate the MANUAL DOOR Opener



2. Use the door handle to slide the door into open position.