 <p>A350 MANUEL SECURITE SAUVETAGE</p>	<p>CABIN LAYOUT</p> <p>CABIN CREW REST AREAS</p> <p>DESCRIPTION/OPERATION</p>
---	---

How to Open the Door from Inside the CCRC

1. Press the OPEN DOOR pb to unlock the door.
2. Within 5 s, use the door handle to slide the door into open position. If not done within 5 s, the door will automatically relock and it will be necessary to repeat the steps 1 and 2.

How to Close the Door

From any side:

1. Use the door handle to slide the door into the closed position.

Note: When the door is entirely closed, it locks automatically.

2. To check that the door is correctly locked:


Try to slide the door into an open position.

If the door opens, it was not correctly locked and it will be necessary to repeat the steps 1 and 2.

HOW TO OPERATE THE DOOR IF REGULAR OPERATION IS NOT POSSIBLE

How to Open the Door from Inside the CCRC

1. Shift the handle of the manual door opener to unlock the door.

 <p>A350 MANUEL SECURITE SAUVETAGE</p>	<p>CABIN LAYOUT</p> <p>CABIN CREW REST AREAS</p> <p>DESCRIPTION/OPERATION</p>
--	---

How to Operate the MANUAL DOOR Opener



2. Use the door handle to slide the door into open position.

CABIN CREW REST COMPARTMENT - THE INTERIOR	
Applicable to: ALL	EASA OSD

The following figure shows the main features/components of the interior of the Cabin Crew Rest Compartment (CCRC).

Note: Depending on the aircraft configuration, the CCRC may not have some of the features/components shown in the figure.