


CAUTION

Do not press the FLUSH pb if it is flashing amber. Otherwise a toilet and faucet maintenance operation (e.g. continuous water flowing) is possible.

Press the FLUSH pb to activate a toilet flush cycle.

FLUSH Pushbutton (Example)



EASA OSD

ATTENDANT CALL PUSHBUTTON

To call the cabin crew for help or assistance, press the ATTENDANT CALL pb.

Note: *These optical indications will come on:*

- *The amber lavatory call light*
- *The assigned light on the ACP*
- *A text message on the assigned AIP.*

To reset the attendant call, press the cabin ATTENDANT CALL pb.

Attendant Call Pushutton (Example)

